NANOPARTICLES/NANOMATERIALS USE COLLEGE PROTOCOL & TRAINING ACKNOWLEDGEMENT

Date		NEW RENEWAL #:	
NAME		CONTACT NUMBER	
EMAIL			
Lab/Research Name	Pilot Plant (1D04) 🗌 Other:	Lab Room Number(s)	
PI Name		PI Phone Number	
Brief description of NP/NM research			
in ynn researen			
Current NP/NM SOP Available			

Nanomaterial safety training provided by Safety Resources: <u>http://safetyresources.usask.ca/services/training/index.php</u>

HEALTH AND SAFETY SUMMARY:

- There is increasing use of nanoparticles/nanomaterials (NP/NM) in laboratories in the College of Engineering (CoE) at the University of Saskatchewan. <u>It is recognized that there are currently unknown risks associated with this work</u>.
- Because of the relative newness of NP/NM in the laboratory research and occupational setting there is limited data relating to the hazards and health and safety risks to personnel and students using NP/NM. However, some evidence that NP/NM are currently unpredictable in their nature and affects, therefore we must all treat NP/NM as high hazard work until we know better about possible lasting health effects.
- The Principal Investigator (PI) is responsible to ensure compliance with this College Protocol and Training Acknowledgement, as well as ensuring written NP/NM standard operating procedures (SOPs or HAZOPs) are completed and up-to-date.
- CSA Standard Z12885-12 "<u>Nanotechnologies Exposure control program for engineered nanomaterials in occupational</u> setting" is available to those working with NP/NM and writing research SOPs & can be signed out for reference at 1D23.
- Annex E of CSA Z12885-12 contains valuable information regarding the use of PPE and fumehoods.

RECOGNIZED HEALTH, SAFETY & ENVIRONMENTAL HAZARDS:

Toxicity: limited data available, *MODERATE TO HIGH RISK*

Eye Contact: may cause irritation, limited data available, *MODERATE RISK*

Inhalation: causes irritation and is possibly carcinogenic, HIGH RISK

Skin Contact: May cause sensitization with prolonged skin contact, limited data available, MODERATE RISK

Ingestion: Lower oral acute toxicity, but may irritate gastrointestinal tract, MODERATE TO HIGH RISK

RULES FOR WORKING WITH NP/NM IN THE College of Engineering:

- 1. Training is required for all users of NP/NM; including use of this protocol and training document;
- 2. Written SOPs (or HAZOP) are required for each specific research activity utilizing or generating NP/NM;
- 3. All NP/NM laboratory research work is to be performed in a FUMEHOOD (or similar controlled environment);
- 4. All NP/NM transport must be securely contained for any transport within labs and between labs;
- 5. All NP/NM waste must be packaged properly as Hazardous Waste and disposed through the university's Waste Management Facility (WMF);
- 6. All NP/NM exposures/leaks/spills must be reported immediately to CoE Local Safety Committee (LSC);
- 7. NP/NM Safety Data Sheets (SDS or MSDS) must be readily available and followed diligently; and,
- 8. Monthly inspection reports for labs using NP/NM are required to be provided to the CoE LSC for review.

SPECIFIC PROTOCOL FOR ELEMENTS OF NP/NM RESEARCH

CHECK TO ACKNOWLEDGE UNDERSTANDING OF EXPECTATIONS RELATING TO NP/NM RESEARCH WORK:

NP/NM PERSONAL PROTECTIVE PROTECTION (PPE) USE:

- □ Wear appropriate lab attire and footwear
- □ Wear good quality puncture resistant and chemical-resistant disposable gloves. For added safety a second layer of gloves can be used, as recommended in the CSA Z12885-12 standard
- □ Wear chemical safety goggles
- □ Avoid contact with eyes, skin or clothing
- Use appropriate respirator or mask to avoid inhaling NP/NM
- □ Minimize the number of employees handling NP/NM

NP/NM GENERATION, USE, STORAGE & TRANSPORT:

- □ All work is to be performed in a FUMEHOOD (or similar controlled environment)
- □ Keep tightly sealed in storage and during any transport (use plastic container with secure lid as secondary containment); utilize secondary containment and rolling carts, as appropriate
- □ Store in a cool, dry and well labelled area ('nanoparticles storage area')
- Do not store together with a) acids, b) oxidizing agents or c) halogens
- □ Minimize NP/NM handling whenever possible

PROPER NP/NM WASTE DISPOSAL:

- □ NP/NM waste material shall be classified and coded as **'nanoparticle hazardous waste'**, and depending on the type of waste it can be either:
 - 1) Double wrapped in sealed polythene bags, and placed in a sturdy card board box or in a plastic pail with a gasket sealed lid and labelled with orange hazardous waste labels, (contaminated disposable gloves, clothing, wipe down cloths, etc.)
 - 2) Placed in a sturdy cardboard box or plastic pail with a gasket sealed lid, and labelled with orange hazardous waste labels, (unused material already in the supplier's container)
- Complete the Hazardous Waste Disposal Form and contact Waste Management Facility to pick up the waste

CLEANING MINOR NP/NM SPILLS OR LEAK REMEDIATION PROCEDURES:

- □ Secure the area before initiating clean up procedures
- □ If exposure is expected, then wear your respirator with HEPA cartridges during clean up procedures
- □ Wear chemical safety goggles
- □ Wear good quality puncture resistant and chemical-resistant disposable gloves
- □ Avoid raising any airborne particulates
- Use good 'wet-wiping' techniques and/or use designated vacuum cleaner, with approved HEPA filter
- □ Wipe up spilled material and place the contaminated wet wipes and gloves in a double bag, seal properly and dispose of through the University of Saskatchewan Waste Management Facility
- □ Wash spill site with hot soapy water and dispose of all NP/NM contaminated waste water through the University of Saskatchewan Waste Management Facility

NP/NM Research Specific SOP(s):

- □ SOP(s) are Current (Date: ______) □ Includes emergency shutdown procedure(s)
- □ SOP(s) are Posted (Location: _____)
 □ MSDS or SDS are readily available: (Location: _____)

□ SOP(s) Reviewed by College of Engineering Local Safety Committee (Date:)

RESEARCHER/GRADUATE STUDENT ACKNOWLEDGEMENT:

SIGNATURE	x	DATE	
-----------	---	------	--

SUPERVISOR REVIEW AND APPROVAL:

NAME		ROLE	PI LSC Other
SIGNATURE	x	DATE	

Fit testing completed